

# Documentation of MesureImages

Click “Open an image” to open a JPEG image (only JPEG images are supported).

You can zoom by dragging the zoom slider, the zoom number updates on the text to its left.

Then put the scale either:

- A DPI scale if you know the number of DPI of your image, if you have scanned it, most often, in this case write the number of DPI.
- A manual scale: in this case put a number of millimeters in the box next to “Manual scale” then click on the “Manual scale” radio button on the right, then draw a segment on the image corresponding to your number of millimeters. To do this, click on the first point then on the second point of the segment.

Then take your measurements:

- For a segment, click on the “Segment” radio button, then click on the first point and then on the second. The measurement is updated on the left of the window
- For an angle, click on the “Angle” radio button then click on the point of one branch of the angle, then on the vertex of the angle (which appears in blue), then on a point of the other branch of the angle. The angle measurement is updated on the left of the window
- For several connected segments, click on the radio button "Segments" then click on the points of the vertices of all these segments. The measurement is updated on the left of the window